

## MC-100 contrast adjustment procedure:

You can adjust the screen contrast of your MC-100 with the up arrow key when the instrument is in a powered up state. In order to be sure it is powered up (since you have no visible display) do the following:



1. Remove the battery and wait 20 seconds
2. Insert a fresh battery being careful to insert it correctly – if you find you need to “force” the battery into the unit, you may have the polarity incorrect.
3. In some cases the unit will beep and the MC-100 logo will show on the screen briefly. The beep indicates the unit is in a powered on state and the brief appearance of the logo confirms that the screen is working and probably just needs a contrast adjustment.
4. If the meter beeps, hold down the up arrow and the screen will cycle the characters' contrast, stop pressing the arrow key when the contrast is to your liking. Note that the screen will cycle through full dark to full light rather quickly.
5. If the meter does not beep when you first put in the battery, that means the unit is not in a power-up condition. Push the power button to turn the meter on and you will hear a beep. You can then cycle the contrast with the up arrow key as described.

Note: Your contrast setting might not be saved if you remove the battery before turning off the unit, or in rare cases, reformatted the memory.